

LAUR SILICONE

LAUR Q-1331 SILICONE RUBBER

DESCRIPTION:

Laur Q-1331 Silicone Rubber is a three-component system intended for making solvent dispersions. When properly mixed and cured, Laur Q-1331 yields a translucent, 50- durometer rubber with a brittle point of -73 °C (-100 °F).

For pigmenting purposes, Laur Q-1331 base dispersed in solvent may be colored to most desired shades by using inorganic heat stable pigments. Pigment masterbatched with a silicone fluid is recommended. Pigment used should be tested to insure compatibility.

USES Laur Q-1331 Silicone Rubber is designed to be dispersed in solvent for coating electrical sleeving and cloth. It satisfies MIL-I-3190-6D (SHIPS) Class 200, Type D, Category C.

TYPICAL PROPERTIES

Material	Q-1331
Durometer, Shore A	51
Tensile, psi	1500
Elongation, %	750
Specific Gravity	1.14
Tear B, ppi	155
Color	Translucent

ALL SLABS MOLDED 10 MINUTES @ 340°F / POST CURE 1 HOUR @150°C

The properties listed here are typical values and are not intended to be used for writing specifications. For assistance in selecting a compound for a specific application, please contact our technical department.

HOW TO USE:

Laur Q-1331 base should be used only with Laur Q-1331 additives. The ratio requires 1 - 3 % of each additive, based on 100 parts of base. For proper level consult product label. Conventional peroxides should NOT be used, as inconsistent properties will result.

MAKING DISPERSIONS:

Choose a suitable mixing vessel; i.e. 5-gallon pail or 55-gallon drum, dependent on volume required. Either a Cowles-type or propeller-type mixer may be used.

The base should first be freshened on a two-roll mill. As soon as possible after freshening, the base should be cut into small pieces and added to the mixing vessel containing the premeasured amount of solvent.

After the Q-1331 base has been uniformly dissolved, the additives should be added. Allow to mix until uniform. Heating of the material should be limited.

Although Laur Q-1331 base is strained, it is recommended that the dispersion be filtered. This will remove contamination introduced during the dispersing process.

Solvent choice rests with the processor, but xylene or toluene are best. Naphtha may be used, but may require longer mixing times.

CAUTION:

When using flammable solvents, keep away from heat, sparks, and open flame. Consult and follow solvent handling instructions.

EXPECTED VISCOSITIES:

When Laur Q-1331 base is properly dispersed, the following viscosities are typical at 31 percent solids in Xylene:

Brookfield Model LVT Viscometer Spindle #3	
6 RPM	29,400 cps
12 RPM	23,250 cps
30 RPM	17,680 cps

Viscosities will rise with extended shelf aging. These values represent freshly made dispersions. Thickened dispersion may be restored to its original viscosity by vigorous stirring.

STORAGE AND SHELF LIFE:

Laur Q-1331 base and additives should be stored away from materials containing sulfur, phosphorous, and amines, as these materials may inhibit vulcanization. Shelf life is three months from date of shipment.

USERS PLEASE READ:

The information and data contained herein we believe reliable; however it is the responsibility of the user to test any application to determine suitability of the goods with respect to proposed usage. Laur Silicone, Inc. warrants that the product shall meet the seller’s specifications and no other expressed or implied warranties are intended. Laur's sole liability is limited to refund or replacement of goods shown to be otherwise as warranted. Suggestions of uses shall not be interpreted as inducement to infringe any particular patent.